


PORTABLE GOALPOST SAFETY NOTICE

Project Goal Alert is a safety initiative of Football NSW

PORTABLE GOALPOST WARNING STICKERS

⚠ WARNING ALWAYS ANCHOR GOAL NEVER CLIMB ON GOAL OR HANG ON CROSSBAR *Unanchored goals can tip over causing serious injury or death.*



As from 1 July 2009 all portable goalposts (weighing 28kg+) must be affixed with three warning stickers. Warning stickers will alert children, players, parents and officials to the dangers of climbing and swinging on portable goalposts.

PORTABLE GOALPOST SAFETY REMINDER



Unanchored Portable Goal



Portable goal anchored by 10 x stakes

All portable goalposts (weighing 28kg+) must be anchored securely using 10 stakes (at least 300mm long) or 12 bags of sand or 10 bags of cement.

Portable goalposts must always be chained up or stored away safely when not in use.



NEVER ALLOW ANYONE TO CLIMB OR SWING ON PORTABLE GOALS



For more information about portable goalpost safety visit
www.footballnsw.com.au or www.fairtrading.nsw.gov.au



